OEL Recommended Spare Parts List

OKIFAX 5650

Revision 6

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environment
						per *	per *	per *			
	CABINET ASSEMBLY	1	PA4120-1079G001	DOCUMENT HOPPER ASSEMBLY	1	*	*	*			
	CABINET ASSEMBLY	2	PP4120-1084P001	SUB-HOPPER PLATE	1	*	*	*			
	CABINET ASSEMBLY	3	41271001	Cover-NCU	1	*	*	*			
	CABINET ASSEMBLY	4	PP4120-1089P001	MAIN COVER	1	*	*	*			
	CABINET ASSEMBLY	5	PA4083-6130G001	MANUAL FEED GUIDE ASSEMBLY	1	*	*	*			
	CABINET ASSEMBLY	6d	41143905	Board-INU	1	*	*	*	NO-EC		
	CABINET ASSEMBLY	6e	41143501	Board-EN9	1	*	*	*	OEL/TENOVIS(BOSCH)		
	CABINET ASSEMBLY	8	PP4120-1088P001	PARTITION PLATE	1	*	*	*			
	CABINET ASSEMBLY	9	PP4120-1090P001	REAR COVER	1	*	*	*			
	CABINET ASSEMBLY	10	PP4120-1093P001	STACKER COVER-FD	1	*	*	*			
	CABINET ASSEMBLY	14	PB4120-1136P001	KNOB SCREW	2	*	*	*			
	CABINET ASSEMBLY	15	41632001	Film-Assist	3	*	*	*			
	CONTROL PANEL ASSEMBLY	1b	41260802	Cover Assy.-OP Panel(OEL)	1	*	*	*	OEL/NO-EC,Note 1		
	CONTROL PANEL ASSEMBLY	2	41261401	Film-Onetouch	2	*	*	*	Note 2		
	CONTROL PANEL ASSEMBLY	3a	41261301	Sheet-Onetouch	1	*	*	*	Note 2		
	CONTROL PANEL ASSEMBLY	4a	41261201	Film-Function	1	*	*	*	OKI,Note 2		
	CONTROL PANEL ASSEMBLY	6a	41261302	Sheet-Onetouch	1	*	*	*	OKI,Note 2		
	CONTROL PANEL ASSEMBLY	7	41261001	Cover-Onetouch	1	*	*	*			
	CONTROL PANEL ASSEMBLY	8	41178701	Board-P60	1	*	*	*			
	CONTROL PANEL ASSEMBLY	9a	40732601	Button-Start	1	*	*	*	OKI		
	CONTROL PANEL ASSEMBLY	10a	40732701	Button-Stop	1	*	*	*	OKI		
	CONTROL PANEL ASSEMBLY	11	40732804	Button-TenKey	1	*	*	*			
	PRINTER ASSEMBLY	1	PA4120-1214G001	STACKER COVER ASSEMBLY	1	*	*	*			
	PRINTER ASSEMBLY	2	PB3517-1567P001	GUIDE WIRE	1	*	*	*			
	PRINTER ASSEMBLY	3	YB4120-1117P001	PULSE MOTOR(MAIN)-151/175	1	*	*	*			
	PRINTER ASSEMBLY	4	YB4120-1118P001	PULSE MOTOR(RESIST)-151/175	1	*	*	*			
	PRINTER ASSEMBLY	5	PP4083-2593P001	IDLE GEAR A	2	*	*	*			
	PRINTER ASSEMBLY	6	PP4083-6076P001	REDUCTION GEAR	1	*	*	*			
	PRINTER ASSEMBLY	8b	YX4120-1128G002	FUSING UNIT ASSEMBLY(230V)	1	*	*	*	Except ODA		
	PRINTER ASSEMBLY	9	PA4122-1295G001	Hopping Roller Assy	1	*	*	*			
	PRINTER ASSEMBLY	10	PP4083-6022P002	BEARING A	4	*	*	*			
	PRINTER ASSEMBLY	11	PP4083-6086G001	TONER SENSOR ASSEMBLY	1	*	*	*			
	PRINTER ASSEMBLY	12	PP4083-6083P001	SENSOR PLATE(IN)	3	*	*	*			
	PRINTER ASSEMBLY	13	PB4083-6024P001	ONE-WAY CLUTCH GEAR	2	*	*	*			
	PRINTER ASSEMBLY	14	PP4083-6080P001	IDLE GEAR B	1	*	*	*			
	PRINTER ASSEMBLY	15	PP4083-6054P001	RESET LEVER R	1	*	*	*			
	PRINTER ASSEMBLY	16	PP4083-6081P001	IDLE GEAR C	1	*	*	*			
	PRINTER ASSEMBLY	17a	PB4083-6030P001	REGISTRATION ROLLER	1	*	*	*			
	PRINTER ASSEMBLY	19	42037001	Roller Assy.-TR_F	1	*	*	*			
	PRINTER ASSEMBLY	20	PB4083-6064P002	BACK-UP ROLLER	1	*	*	*			
	PRINTER ASSEMBLY	21	PP4083-6052P001	BUSH A	2	*	*	*			
	PRINTER ASSEMBLY	22	PP4083-6065P001	BIAS SPRING A	2	*	*	*			
	PRINTER ASSEMBLY	23	PP4083-6035G001	LOWER BASE SUBASSEMBLY	1	*	*	*			
	PRINTER ASSEMBLY	24	PP4083-6058P001	SWITCH ARM LEVER	1	*	*	*			

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year per *	per *	per *	Remarks	Del/ Add	Remarks for environment
	PRINTER ASSEMBLY	25	PP4083-6053P001	RESET LEVER L	1	*	*	*			
	PRINTER ASSEMBLY	26	PP4083-6057P001	RESET SPRING	1	*	*	*			
	PRINTER ASSEMBLY	27	PB4083-6197P001	DAMPER FRAME	1	*	*	*			
	PRINTER ASSEMBLY	28	PP4083-6191G001	DAMPER ARM ASSEMBLY	1	*	*	*			
	PRINTER ASSEMBLY	29	PA4083-6025G001	EJECT SENSOR LEVER ASSEMBLY	1	*	*	*			
	PRINTER ASSEMBLY	30	PA4120-1129G001	EJECT ROLLER ASSEMBLY F	1	*	*	*			
	PRINTER ASSEMBLY	31	PA4120-1085G001	RELEASE GUIDE ASSEMBLY	1	*	*	*			
	PRINTER ASSEMBLY	32	PP4120-1087P001	RELEASE SPRING	1	*	*	*			
	PRINTER ASSEMBLY	33	YA4116-1228G001	LED HEAD GENERAL SPEC.-31B	1	*	*	*			
	PRINTER ASSEMBLY	34	2241002P0140	PX14B	1	*	*	*	*1		
	PRINTER ASSEMBLY	35	41857101	LED CABLE ASSEMBLY	1	*	*	*	*1		
	PRINTER ASSEMBLY	42	40778901	SENSOR WIRE ASSEMBLY	1	*	*	*			
	PRINTER ASSEMBLY	43	PP4120-1209P001	WASHER B	1	*	*	*			
	PRINTER ASSEMBLY	44	PP4120-1210P001	WASHER C	1	*	*	*			
	PRINTER ASSEMBLY	45	PP4083-6071G001	MOTOR PLATE ASSEMBLY	1	*	*	*			
	PRINTER ASSEMBLY	46a	PB4120-1105P001	HALOGEN LAMP(Q)-F120	1	*	*	*			
	PRINTER ASSEMBLY	46b	PB4120-1105P002	HALOGEN LAMP(Q)-F230	1	*	*	*			
	PRINTER ASSEMBLY	47	PB4083-6106P001	HEAT SENSOR	1	*	*	*			
	PRINTER ASSEMBLY	48	PB4083-6293P001	THERMOSTAT A	1	*	*	*			
	PRINTER ASSEMBLY	49	PB4083-6128P001	BEARING B	2	*	*	*			
	PRINTER ASSEMBLY	50	PP4083-6113P001	GEAR A	1	*	*	*			
	PRINTER ASSEMBLY	51	PP4083-6031P001	BEARING R	1	*	*	*			
	PRINTER ASSEMBLY	52	40559101	Spring-Compression R(I/D)	2	*	*	*			
	BASE ASSEMBLY	1b	41067001	PWR unit-ACDC Switch	1	*	*	*	(230V) Except ODA		
	BASE ASSEMBLY	2	PA4083-6090G001	CONTACT ASSEMBLY	1	*	*	*			
	BASE ASSEMBLY	3	41144001	Board-H08	1	*	*	*			
	BASE ASSEMBLY	4a	41616402	PCB Unit-M60-2	1	*	*	*	* 1		
	BASE ASSEMBLY	4b	41900801	Board-M60-2 Spare parts	1	*	*	*	* 2		
	BASE ASSEMBLY	5	YX4076-7012G001	CASSETTE GUIDE R ASSEMBLY	1	*	*	*			
	BASE ASSEMBLY	6	PP4083-7653P001	CASSETTE LOCK LEVER	2	*	*	*			
	BASE ASSEMBLY	7	PP4083-7655P001	CASSETTE LOCK SPRING	2	*	*	*			
	BASE ASSEMBLY	8	PP4122-1170P001	LINK PULL LEVER	2	*	*	*			
	BASE ASSEMBLY	9	PP4083-7666P001	SHEET SPRING	2	*	*	*			
	BASE ASSEMBLY	10	PP4083-7658G001	SHEET LINK R ASSEMBLY	1	*	*	*			
	BASE ASSEMBLY	11	PA4120-1162G001	PAPER CASSETTE ASSEMBLY	1	*	*	*			
	BASE ASSEMBLY	12	40259701	Frame Assy.-Sepa.	1	*	*	*			
	BASE ASSEMBLY	13	PP4083-7660P001	BEAM PLATE	2	*	*	*			
	BASE ASSEMBLY	14	PA4076-7011G001	CASSETTE GUIDE L ASSEMBLY	1	*	*	*			
	BASE ASSEMBLY	15	PP4120-1078P001	BASE PLATE	1	*	*	*			
	BASE ASSEMBLY	16	PP4083-6154P001	CASSETTE DETECTION LEVER	1	*	*	*			
	BASE ASSEMBLY	17	PP4083-7667P001	PAPER END SENSOR LEVER	1	*	*	*			
	BASE ASSEMBLY	18	PB4120-1103P001	INSULATOR PLATE	1	*	*	*			
	BASE ASSEMBLY	19	41348401	Motor-Fan_DC	1	*	*	*			
	BASE ASSEMBLY	25	PP4083-7657G001	SHEET LINK L ASSEMBLY	1	*	*	*			

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environment
						per *	per *	per *			
	BASE ASSEMBLY	26	PP4083-7662P001	FG PLATE C	1	*	*	*			
	BASE ASSEMBLY	31	41861904	Card-I/F Spare parts	1	*	*	*	Option		
	BASE ASSEMBLY	33	PP4083-7665P001	FG PLATE D	1	*	*	*			
	BASE ASSEMBLY	34	YC4061-5115P001	POLYETHYLENE TAPE	2	*	*	*			
	BASE ASSEMBLY	41	41319501	Bracket-Support_PSU	2	*	*	*			
	BASE ASSEMBLY	42	41076201	Spacer-Rubber_PSU	1	*	*	*			
	SCAN UNIT	1	PP4120-1015P001	SCANNER FRAME	1	*	*	*			
	SCAN UNIT	2	PP4120-1034P001	SCANNER BASE FRAME L	1	*	*	*			
	SCAN UNIT	3	PP4120-1023P001	EARTH PLATE ADF	1	*	*	*			
	SCAN UNIT	4	PP4120-1017P001	PC2 LEVER	1	*	*	*			
	SCAN UNIT	5	PP4120-1016P001	PC1 LEVER	1	*	*	*			
	SCAN UNIT	6	PP4120-1038P001	POCKET PLATE	1	*	*	*			
	SCAN UNIT	7	PP4120-1037P001	SCANNER BASE FRAME R	1	*	*	*			
	SCAN UNIT	8	PP4120-1032P001	LATCH SPRING	2	*	*	*			
	SCAN UNIT	9	PP3529-5045P001	PINCH ROLLER	1	*	*	*			
	SCAN UNIT	10	PP4120-1020P001	PINCH ROLLER SHAFT	1	*	*	*			
	SCAN UNIT	11	PP4120-1022P001	PINCH SPRING R	1	*	*	*			
	SCAN UNIT	12	PP4120-1021P001	PINCH SPRING L	1	*	*	*			
	SCAN UNIT	13	PP3529-5033P001	GEAR(Z20)	1	*	*	*			
	SCAN UNIT	14	PA3529-5082G001	SUB-ROLLER ASSEMBLY	1	*	*	*			
	SCAN UNIT	15	PP4120-1029P001	SCANNER BOTTOM PLATE	1	*	*	*			
	SCAN UNIT	16	PP3529-5039P001	GEAR(Z81/15)	1	*	*	*			
	SCAN UNIT	17	PB3527-5803P001	MINI CLAMP HOLDER	4	*	*	*			
	SCAN UNIT	18	40135301	Photo-Interrupter	2	*	*	*			
	SCAN UNIT	19	PP4120-1030P001	SENSOR SPRING	1	*	*	*			
	SCAN UNIT	20	40141401	Contact Image Sensor	1	*	*	*	300DPI		
	SCAN UNIT	21	PA4120-1018G001	ADF ROLLER ASSEMBLY	1	*	*	*			
	SCAN UNIT	22	40047601	Motor-S(FX-VP)	1	*	*	*			
	SCAN UNIT	24	PB4120-1024P001	EJECT PINCH ROLLER	1	*	*	*			
	SCAN UNIT	25	PP4120-1025P001	EJECT PINCH SPRING	2	*	*	*			
	PAPER GUIDE U ASSEMBLY	1	PA4120-1045G001	FEED ROLLER(1)ASSEMBLY	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	2	PP4120-1226P001	Earth-Plate(SR)	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	3	PP4120-1227P001	Earth-Plate(SL)	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	4	YS4011-1714P002	EARTH CORD	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	5	PP4120-1040P001	PAPER GUIDE U	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	6	PA4120-1041G001	PINCH PLATE ASSEMBLY	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	7	PB4120-1051P001	DISELECTRIFICATION BRUSH	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	8	PP3529-5035P001	GEAR(Z28)	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	9	PA3529-5087G001	SEPARATION RUBBER ASSEMBLY	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	10	PA4120-1049G001	SENSOR ROLLER ASSEMBLY	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	11	PP3529-5034P001	GEAR(Z22)	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	12	PA4120-1052G001	EXIT ROLLER ASSEMBLY	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	13	PP3527-5153P001	BACK-UP PLATE	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	14	PP4120-1044P001	ADF SPRING	1	*	*	*			

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year per *	per *	per *	Remarks	Del/ Add	Remarks for environment
	PAPER GUIDE U ASSEMBLY	15	PB4120-1051P002	DISELECTRIFICATION BRUSH	2	*	*	*			
	PAPER GUIDE U ASSEMBLY	16	PP3522-3568P001	BEARING ADF	2	*	*	*			
	PAPER GUIDE U ASSEMBLY	18	YS4011-1714P003	EARTH CORD	1	*	*	*			
	PAPER GUIDE U ASSEMBLY	19	PP3527-5034P001	GEAR(Z16)	2	*	*	*			
	PAPER GUIDE U ASSEMBLY	20	PB4013-3501P003	CS-RING(CS4-SUS)	2	*	*	*			
	CABLES	1	40040002	CONN Cord-Wire(OPE)	1	*	*	*			
	CABLES	2	YB4120-1026P001	SPEAKER	1	*	*	*			
	CABLES	3	YS4111-3527P002	CONNECTOR CORD	1	*	*	*			
	CABLES	4	YS4111-3441P001	CONNECTOR CORD(CIS)	1	*	*	*	(CIS)		
	CABLES	5	YS4111-3442P001	CONNECTOR CORD(PC1/2)	1	*	*	*	(PC1/2)		
	CABLES	6	1051070C0001	TFC-16813	2	*	*	*	(FAN/Speaker)		
	CABLES	7c	236A6058P0001	4622-007-0092	1	*	*	*	OEL,Note 3		
	CABLES	8	YS4111-5581P001	CORD(TEL1-TEL2)	1	*	*	*			
	CABLES	10	105A1051C3002	TR-28-16-20	1	*	*	*	(2nd Tray Cable)		
	CABLES	14	105A1068C1004	SFC-8	1	*	*	*	(Line Cable)		
	CABLES	15	105A1070C0004	TFC-23-11-14	1	*	*	*	(OPE Cable)		
	CABLES	16	105A1070C0003	TFC-20-10-10	1	*	*	*	(Sensor Cable)		
	CABLES	17	YB4120-1094P001	SECONDARY BATTERY	1	*	*	*			
	CABLES	18	LP-1466	SNAP BAND	*	*	*	*			
	CABLES	19	LP-6401-B1	TYING CORD	1	*	*	*			
	CABLES	22	40808001	CONN Cord-PSU(High/Low)	1	*	*	*			
	OPTION TELEPHONE(US)	1	PP4120-1095P011	Cradle	1	*	*	*			
	OPTION TELEPHONE(US)	2	YA4129-1006G001	Board-HOOK	1	*	*	*			
	OPTION TELEPHONE(US)	6	YA4129-1005G001	Board-TELU	1	*	*	*			
	OPTION TELEPHONE(US)	7	PP4120-1096P001	Base-Cradle	1	*	*	*			
	OPTION TELEPHONE(US)	8	PP4120-1097P001	Cover-Terminal	1	*	*	*			
	OPTION TELEPHONE(US)	9	PA4120-1140G001	Attachment-Assy	1	*	*	*			
	OPTION TELEPHONE(US)	10	YB3512-2029G004	Handset	1	*	*	*			
	OPTION TELEPHONE(US)	12	YS4111-5552P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(US)	14	YS4111-5551P001	Moduler-Jack-Cord	1	*	*	*			
	OPTION TELEPHONE(US)	17	YS3522-1252G002	Cord-Handset	1	*	*	*			
	OPTION TELEPHONE(US)	20	PB4120-1136P001	KNOB SCREW	1	*	*	*			
	OPTION TELEPHONE(US)	21	PB4016-1960P001	Rubber Foot	4	*	*	*			
	OPTION TELEPHONE(AG)	1	PP4120-1095P012	Cradle	1	*	*	*			
	OPTION TELEPHONE(AG)	2	YA4129-1006G001	Board-HOOK	1	*	*	*			
	OPTION TELEPHONE(AG)	6	YA4129-1005G001	Board-TELU	1	*	*	*			
	OPTION TELEPHONE(AG)	7	PP4120-1096P002	Base-Cradle	1	*	*	*			
	OPTION TELEPHONE(AG)	8	PP4120-1097P002	Cover-Terminal	1	*	*	*			
	OPTION TELEPHONE(AG)	9	PA4120-1140G001	Attachment-Assy	1	*	*	*			
	OPTION TELEPHONE(AG)	10	YB3512-2029G001	Handset	1	*	*	*			
	OPTION TELEPHONE(AG)	12	YS4111-5552P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(AG)	14	YS4111-5551P001	Moduler-Jack-Cord	1	*	*	*			
	OPTION TELEPHONE(AG)	17	YS3522-1252G002	Cord-Handset	1	*	*	*			
	OPTION TELEPHONE(AG)	20	PB4120-1136P001	KNOB SCREW	1	*	*	*			

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environment
						per *	per *	per *			
	OPTION TELEPHONE(AG)	21	PB4016-1960P001	Rubber Foot	4	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	1	PP4120-1095P011	Cradle	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	2	YA4129-1006G001	Board-HOOK	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	3	PP4120-1068P001	TEN KEY	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	4	YA4129-1003G001	Board-Tenkey	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	5	YU3528-1022G014	Board-TEL W1	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	6	YA4129-1004G001	Board-NTIF	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	7	PP4120-1096P001	Base-Cradle	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	8	PP4120-1097P001	Cover-Terminal	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	9	PA4120-1140G001	Attachment-Assy	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	10	YB3512-2029G004	Handset	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	11	YS4111-5553P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	12	YS4111-5552P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	13	YS4111-5556P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	14	YS4111-5551P001	Moduler-Jack-Cord	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	15	YS4111-5554P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	16	YS4111-5555P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	17	YS3522-1252G002	Cord-Handset	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	20	PB4120-1136P001	KNOB SCREW	1	*	*	*			
	OPTION TELEPHONE(UK,ITA,NOR,DE)	21	PB4016-1960P001	Rubber Foot	4	*	*	*			
	OPTION TELEPHONE(ABX)	1	PP4120-1095P002	Cradle	1	*	*	*			
	OPTION TELEPHONE(ABX)	2	YA4129-1006G001	Board-HOOK	1	*	*	*			
	OPTION TELEPHONE(ABX)	3	PP4120-1068P002	TEN KEY	1	*	*	*			
	OPTION TELEPHONE(ABX)	4	YA4129-1003G001	Board-Tenkey	1	*	*	*			
	OPTION TELEPHONE(ABX)	5	YU3528-1022G014	Board-TEL W1	1	*	*	*			
	OPTION TELEPHONE(ABX)	6	YA4129-1004G001	Board-NTIF	1	*	*	*			
	OPTION TELEPHONE(ABX)	7	PP4120-1096P002	Base-Cradle	1	*	*	*			
	OPTION TELEPHONE(ABX)	8	PP4120-1097P002	Cover-Terminal	1	*	*	*			
	OPTION TELEPHONE(ABX)	9	PA4120-1140G001	Attachment-Assy	1	*	*	*			
	OPTION TELEPHONE(ABX)	10	YB3512-2029G001	Handset	1	*	*	*			
	OPTION TELEPHONE(ABX)	11	YS4111-5553P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(ABX)	12	YS4111-5552P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(ABX)	13	YS4111-5556P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(ABX)	14	YS4111-5551P001	Moduler-Jack-Cord	1	*	*	*			
	OPTION TELEPHONE(ABX)	15	YS4111-5554P001	Connection-Cord	1	*	*	*			

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environment
						per *	per *	per *			
	OPTION TELEPHONE(ABX)	16	YS4111-5555P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(ABX)	17	YS3522-1252G002	Cord-Handset	1	*	*	*			
	OPTION TELEPHONE(ABX)	20	PB4120-1136P001	KNOB SCREW	1	*	*	*			
	OPTION TELEPHONE(ABX)	21	PB4016-1960P001	Rubber Foot	4	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	1	PP4120-1095P011	Cradle	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	2	YA4129-1006G001	Board-HOOK	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	5a	YU3528-1037G011	Board-TEL11	1	*	*	*	SWITZ, AUS		
	OPTION TELEPHONE(HOL,GER,FRA,S)	5b	YU3528-1037G003	Board-TEL3	1	*	*	*	HOL, OEL-INT'L		
	OPTION TELEPHONE(HOL,GER,FRA,S)	5c	YU3528-1038G013	Board-TEL13	1	*	*	*	GER		
	OPTION TELEPHONE(HOL,GER,FRA,S)	5d	YU3528-1033G018	Board-TEL W2F	1	*	*	*	FRA		
	OPTION TELEPHONE(HOL,GER,FRA,S)	5e	YU3528-1037G007	Board-TEL7	1	*	*	*	OKI-INT'L		
	OPTION TELEPHONE(HOL,GER,FRA,S)	6a	YA4129-1004G002	Board-NTIF	1	*	*	*	SWITZ, AUS		
	OPTION TELEPHONE(HOL,GER,FRA,S)	6b	YA4129-1004G003	Board-NTIF	1	*	*	*	HOL, OEL-INT'L, GER, OKI-INT'L		
	OPTION TELEPHONE(HOL,GER,FRA,S)	6c	YA4129-1004G004	Board-NTIF	1	*	*	*	FRA		
	OPTION TELEPHONE(HOL,GER,FRA,S)	7	PP4120-1096P001	Base-Cradle	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	8	PP4120-1097P001	Cover-Terminal	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	9	PA4120-1140G001	Attachment-Assy	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	10	YB3512-2029G004	Handset	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	11	YS4111-5553P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	12	YS4111-5552P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	14	YS4111-5551P001	Moduler-Jack-Cord	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	16	YS4111-5555P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	17	YS3522-1252G002	Cord-Handset	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	20	PB4120-1136P001	KNOB SCREW	1	*	*	*			
	OPTION TELEPHONE(HOL,GER,FRA,S)	21	PB4016-1960P001	Rubber Foot	4	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	1	PP4120-1095P012	Cradle	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	2	YA4129-1006G001	Board-HOOK	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	5a	YU3528-1037G011	Board-TEL11	1	*	*	*	ABB		
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	5b	YU3528-1037G009	Board-TEL9	1	*	*	*	AB		
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	5c	YU3528-1038G013	Board-TEL13	1	*	*	*	FTZ		
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	5d	YU3528-1033G018	Board-TEL W2F	1	*	*	*	FR		

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environment
						per *	per *	per *			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	6a	YA4129-1004G002	Board-NTIF	1	*	*	*	ABB		
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	6b	YA4129-1004G003	Board-NTIF	1	*	*	*	AB, FTZ		
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	6c	YA4129-1004G004	Board-NTIF	1	*	*	*	FR		
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	7	PP4120-1096P002	Base-Cradle	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	8	PP4120-1097P002	Cover-Terminal	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	9	PA4120-1140G001	Attachment-Assy	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	10	YB3512-2029G001	Handset	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	11	YS4111-5553P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	12	YS4111-5552P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	14	YS4111-5551P001	Moduler-Jack-Cord	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	16	YS4111-5555P001	Connection-Cord	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	17	YS3522-1252G002	Cord-Handset	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	20	PB4120-1136P001	KNOB SCREW	1	*	*	*			
	OPTION TELEPHONE(ABB,AB,FTZ,FR)	21	PB4016-1960P001	Rubber Foot	4	*	*	*			
	Paper Feeder	1	PP4122-1401P001	Upper Plate	1	*	*	*			
	Paper Feeder	2	PA4122-1370G001	Sheet guide assembly	1	*	*	*			
	Paper Feeder	3	PA4122-1369G001	Front cover assembly	1	*	*	*			
	Paper Feeder	4	PA4122-1371G001	Inner guide assembly	1	*	*	*			
	Paper Feeder	5	PA4122-1362G004	Cassette assembly	1	*	*	*			
	Paper Feeder	6	PA4120-1009G001	Separation frame assembly	1	*	*	*			
	Paper Feeder	7	PP4122-1323P001	Rear Cover	1	*	*	*			
	Paper Feeder	8	PB4122-1441P001	Stick finger	1	*	*	*			
	Paper Feeder	9	PA4122-1366G001	Hopping flame assembly	1	*	*	*			
	Paper Feeder	10	PP3522-3568P001	BEARING ADF	1	*	*	*			
	Paper Feeder	11	PP4122-1207P001	Gear (Z70)	1	*	*	*			
	Paper Feeder	12	PP4122-1331P001	Lever sensor (P)	1	*	*	*			
	Paper Feeder	13	PA4122-1393G001	Feed roller assembly	1	*	*	*			
	Paper Feeder	14	YS4111-3528P001	Connector cable	1	*	*	*			
	Paper Feeder	15	PB4122-1399P001	Stepping motor	1	*	*	*			
	Paper Feeder	16	PP4122-1384G001	Bracket	1	*	*	*			
	Paper Feeder	17	PP4122-1383P001	Gear (Z24)	2	*	*	*			
	Paper Feeder	18	PP4122-1226P001	Gear (Z87/Z60)	1	*	*	*			
	Paper Feeder	19	PP4122-1389P001	Plate-Bottom	1	*	*	*			
	Paper Feeder	20	PA4122-1365G001	2nd cassette guide (L) assy	1	*	*	*			
	Paper Feeder	21	PA4122-1367G001	Hopping roller assembly	1	*	*	*			
	Paper Feeder	22	YX4122-1364G002	Second Guide (R) Assy	1	*	*	*			
	Paper Feeder	23	PB4122-1382P001	One-way gear (Z32)	1	*	*	*			

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	Remarks for environment
						per *	per *	per *			
	Paper Feeder	24	YA4046-1651G002	TQSB-2 PCB	1	*	*	*			
	Paper Feeder	25	PA4122-1372G001	Tail Guide Assy	1	*	*	*			
	Paper Feeder	26	PP4122-1238P002	Separation Spring	1	*	*	*			
	Paper Feeder	27	PP4122-1184P001	Lever Cassette Lock	1	*	*	*			
	Paper Feeder	28	PP4122-1347P001	Lock Spring	1	*	*	*			
	Paper Feeder	29	PP4122-1217P001	Link-Pull_Lever	1	*	*	*			
	Paper Feeder	30	PP4122-1398P002	Sheet Spring	1	*	*	*			
	Paper Feeder	31	PP4122-1339G001	Sheet Link (L)	1	*	*	*			
	Paper Feeder	32	PP4122-1338G001	Sheet Link (R)	1	*	*	*			